
## Concealed basin mixer

2772228 / 2772159 / 2772183 / 2772189 / 2772201/ 2772210



**INSTALLATION INSTRUCTIONS** 

#### INTRODUCTION

Please read these instructions carefully and keep in a safe place for future reference.

#### **General Installation Requirements.**

The installation must comply with regulations of the Local Water Authority as contained in their bylaws. All of the taps in the range are single flow (the hot and cold water mix in the body) and should therefore be supplied with hot and cold water at balanced pressures, both from the tank or both from the mains (via a combination boiler for example). If the taps are not supplied at balanced pressures then the mixer will not function correctly. It will also be necessary to fit non-return valves on both hot and cold feeds. It is very important that all pipework is flushed thoroughly after installation to avoid damaging the ceremic discs.

#### **WARNING**

Before installing the new mixer it is essential that you thoroughly flush through the supply pipes in order to remove any remaining swarf, solder or other impurities. Failure to carry out this simple procedure could cause problems or damage to the working of the mixer.

These hints have been prepared for you guidance, you must exertise due care at all times. We do not take responsibility for any problems that may occur through incorrect installation.

#### **GENERAL INSTALLATION**

These fittings are mixing devices and therefore water supplies must be reasonably balanced.

Before making any inlet pipe connections, all supply pipes MUST be thoroughly flushed to remove debris. Failure to do so could result in damage or low flow from the mixer unit.


The fitting of isolating valves to the inlet feeds is advised for ease of maintenance. Please take great care when installing this mixer not to damage its surface.

Please note if installing in an enclosed environment, access should be left for servicing and maintenance. No costs relating to inadequate access can be accepted.


1

# OPERATION SPECIFICATIONS

Operating Pressure Maximum:5bar Minimum:0.2 bar



# INSTALLATION




### MAINTENANCE OF THE MIXER

Our products are finished to the highest standard and due care needs to be taken to ensure their looks are retained.

We recommend cleaning all products with a soft damp cloth only and wax, advise strongly against the use of all cleaning products i.e. powders and liquids.


If the above instructions are not followed this will invalidate your guarantee in the event of a problem occurring.



### INSTALLATION

Before installing your new mixer, flush through the pipe work to ensure removal of debris, turn off the water supply.

Screw the two flexible pipes to the mixer body, tighten using the correct size spanner, but do not over tighten.



3